

SCALETEC[®]

P L U S



Pool Surface - Tile Calcium and Stain Remover

De-scales Pool Surfaces and Tile *Without Acid Washing, Draining, or Scrubbing!*

Removes Calcium-Lime Scales, Scum Buildup, Iron and Other Stains.

Prevents New Calcium Buildup and Metal Stains: (iron, copper, & manganese).

Scale Removal - Quick Start Guide: Chlorine Pools:

1. Lower chlorine levels to within 1 to 3 ppm.
2. Add Scaletec Plus dosage (use chart) directly to pool water.
3. Operate pool recirculating pump as normal cycle.
4. Maintain chlorine levels at 1 to 3 ppm and pH at 7.2 to 7.8.

Scale Removal - Quick Start Guide: Salt Cell Pools:

1. Lower chlorine levels to within 1 to 3 ppm.
2. TURN OFF SALT CELL GENERATOR for 1 to 2 weeks.
3. Add Scaletec Plus dosage (use chart) directly to pool water.
3. Operate pool recirculating pump as normal cycle.
4. Maintain chlorine levels at 1 to 3 ppm and pH at 7.2 to 7.8.
5. Use liquid or chlorine tablets as alternate chlorine source.

DURING cleanup period (all pools):

1. Waterline calcium scales: raise and maintain water level above scale line. Scrubbing helps improve scale removal.
2. Do not chlorine shock pool.
3. For heavy or old, hard scale: allow up to several months for scale removal. Repeat dosages may be required.

AFTER cleanup period: use Beautec Scale and Stain Controller, to continue cleaning surfaces and provide long lasting protection.